

DOOR PLAQUE INSTALLATION

CONTACT US ON: 01352 79200 - FOR ANY ASSISTANCE

2. Fix face panel to foamex by placing face panel centrally against foamex backing panel and apply pressure to ensure tape can bond successfully.

Ensure foamex backing panel has been cleaned sufficiently so no debris is present to disrupt the bonding of the tape.

1. Fix 5mm foamex backing panel to structure (screws and wallplugs provided are suitable for brick structures ONLY).

